

Mi-T-M[®] CORPORATION

8650 Enterprise Drive, Peosta IA 52068

563-556-7484 / Fax 563-556-1235

www.mitm.com

PARTS LIST FOR ***CA-2504-0MHB/0MRB***

ENGINE OIL GRADE:

SAE10W-30

ENGINE OIL CAPACITY:

37 oz.

PUMP OIL GRADE:

Mi-T-M #AW-4085-0016

PUMP OIL CAPACITY:

14 oz.

PRESSURE NOZZLE SIZE:

5.0

This Parts Listing has been compiled for your benefit. You can be assured your Mi-T-M Cold Water Pressure Washer was constructed and designed with quality and performance in mind using over 25 years experience in the pressure washer business. Each component has been rigorously tested to insure the highest level of acceptance.

The contents of this Parts Listing are based on the latest product information available at the time of publication. Mi-T-M reserves the right to make changes in price, color, materials, equipment, specifications or models at any time without notice.

WARNING

THIS IS A PROFESSIONAL HIGH PRESSURE, COLD WATER PRESSURE WASHER. CAUTION SHOULD BE OBSERVED WHEN USING OR REPAIRING THIS UNIT! READ AND FOLLOW THE SAFETY WARNINGS LISTED BELOW BEFORE ATTEMPTING ANY REPAIRS ON THIS PRESSURE WASHER!

SAFETY WARNINGS

- 1. NEVER alter or modify the equipment. Be sure any accessory items and system components being used will withstand the pressure developed. Use only genuine Mi-T-M parts for repair of your pressure washer. Failure to do so can cause hazardous operating conditions and will VOID warranty.
- 2. NEVER make adjustments on machinery while the unit is connected to the power source. Turning over the machinery by hand during adjustment or cleaning might start the machinery, causing serious injury to the operator.
- 3. Know how to stop and bleed pressures quickly. Be thoroughly familiar with controls.
- 4. Before servicing the unit, turn unit off, relieve the water pressure and allow the unit to cool down. Do not make repairs while the unit is running. Service in a clean, dry, flat area.
- 5. After testing the machine, DO NOT leave the pressurized unit unattended. Shut off the unit and release trapped pressure before leaving.

Table of Contents

SPECIFICATIONS.....3

FRAME ASSEMBLY FOR CA-2504-0MHB/0MRB.....4

PUMP ASSEMBLY (3-0272)6


UNLOADER ASSEMBLY (8-0456)8

GUN ASSEMBLY (16-0001)10

SPECIFICATIONS

MODEL NUMBER	CA-2504-0MHB	CA-2504-0MRB
Operating Pressure (PSI/Bar):	2500/172.4	
High Pressure Nozzle:	5.0	
Water Volume (GPM/lpm):	4.0/15.1	
Engine:	Honda	Subaru
Horsepower	9.0	
Engine Type	4 Stroke, Overhead Valve, Single Cylinder	
Oil Type	SAE10W-30	
Oil Capacity (oz./liters)	37/1.1	
Low Oil Protection	Oil Alert™	Low Oil Shutdown
Fuel Type	Unleaded Gasoline 86 Octane Minimum	
Fuel Capacity (gallon/ liters)	1.6/6.0	
Starting	Recoil	
Maximum No Load RPM	3600 (+/- 100) RPM	
Pump:	Direct Driven, Oil Bath, Triplex Piston	
Oil Type	Mi-T-M Pump Oil #AW-4085-0016	
Oil Capacity (oz./liters)	14/.4	
Plungers	Ceramic	
Manifold	Forged Brass	
Valves	Stainless Steel	
Unloader	Adjustable	
Thermal Relief Valve	Relieves heated water during unloader bypass stage	
Unit Net Weight (lbs/Kg)	105/47.6	
Unit Shipping Weight (lbs/Kg)	155/70.3	
Unit Net Dimension (in/cm)	42.5Lx23.5Wx25H/108Lx60Wx63.5H	
Unit Shipping Dimension (in/cm)	39.5Lx25Wx31.5H/100Lx63.5Wx80H	


FRAME ASSEMBLY FOR CA-2504-0MHB/0MRB



CA-2504-0MHB/R-052505-JJT

FRAME ASSEMBLY FOR CA-2504-0MHB/0MRB								
REF. #	DESCRIPTION	PART #	QTY.		REF. #	DESCRIPTION	PART #	QTY.
1	Front Handle Assembly	7-0182	1		25	Nozzle- 1505	18-0004	1
2	Locknut	30-0157	22		-	Nozzle- 2505	18-0153	1
3	Support Bracket	56-0054	1		26	Decal- Warning/Caution/Operation (See 34-9014)	N/A Sep.	1
4	Isolator	14-0008	2		27	Decal- 2500 Die Cut	34-0773	1
5	Bolt	27-0068	2		28	Inlet Filter Washer w/ Screen	19-0001	1
6	Bolt	27-0067	12		29	Garden Hose Swivel	23-0095	1
7	Decal- Data Plate	N/A	1		30	Pump	3-0272	1
8	Baseplate	5-0207	1		31	Pressure Hose Assembly (Inc. 32-34)	851-0007	1
9	Hub Cap	33-0018	2		32	Quick Connect Plug	17-0006	1
10	Wheel	14-0017	2		33	Hose	15-0003	1
11	Washer	28-0008	6		34	Quick Connect Socket	17-0004	2
12	Axle Spacer	62-0189	2		35	O-ring	25-0123	2
13	Axle	20-0748	1		36	Bolt	27-0118	4
14	Bushing	62-0175	2		37	Lockwasher	29-0008	4
15	Rear Handle	7-0183	1		38	Washer	28-0022	4
16	Vibration Isolator	14-0097	4		39	Key	43-0078	1
17	Isolation Plate	56-0053	1		40	Thermal Relief Valve	22-0005	1
18	Bolt	27-0121	4		41	Gun/Wand Assembly (Inc. 42-47)	851-0095	1
19	Flatwasher	28-0023	8		42	Quick Connect Plug	17-0005	1
20	Locknut	30-0159	4		43	Trigger Gun	16-0001	1
21	Engine- 9.0 HP Honda (CA-2504-0MHB)	1-0065	1		44	Wand Grip	7-0002	1
-	Engine- 9.0 HP Subaru (CA-2504-0MRB)	1-0134	1		45	Wand w/Handle	16-0418	1
22	Decal- Warning: Risk of Burns (See 34-9014)	N/A Sep.	1		46	Decal- Warning: Risk of Injection (See 34-9014)	N/A Sep.	1
23	Decal- Caution: Risk of Fire (See 34-9014)	N/A Sep.	1		47	Quick Connect Socket	17-0001	1
24	Grommet	33-0001	5	48	O-ring	25-0122	1	
25	Nozzle- 0005	18-0003	1		Decal Kit (Inc. 22-23, 26, 46)	34-9014		
*Must Order in One Foot Lengths								

PUMP ASSEMBLY (3-0272)




3-0261-051005-JJT

PUMP ASSEMBLY (3-0272)

REF. #	DESCRIPTION	PART #	QTY.	REF. #	DESCRIPTION	PART #	QTY.	REF. #	DESCRIPTION	PART #	QTY.
1	Screw	27-8432	4	18	Piston Pin	46-0721	3	35	Unloader	8-0456	1
2	Pump Flange	46-0714	1	19	Plunger Rod	46-0722	3	36	Plug	39-0097	1
3	Oil Seal	26-0192	1	20	Washer	28-1027	3	37	Lockwasher	29-0153	8
4	Retaining Ring	46-0667	1	21	O-ring	25-0371	3	38	Screw	27-8875	8
5	Bearing	48-0059	1	22	Piston	46-0723	3	39	Manifold	46-0730	1
6	Screw	27-8886	1	23	Washer	26-0187	3	40	O-ring	25-0372	1
7	Crankshaft	N/A	1	24	Nut	30-6016	3	41	Plug	39-0088	1
8	Plug	39-0086	3	25	Oil Dipstick	39-0090	1	42	Support Ring (See 70-0182)	N/A Sep.	3
9	O-ring	25-0325	3	26	Pump Crankcase	46-0724	1	43	V-Packing (See 70-0181)	N/A Sep.	3
10	Screw	27-8888	6	27	Ball Bearing	48-0063	1	44	Packing Retainer	46-0728	3
11	Crankcase Cover	46-0719	1	28	External Snap Ring	46-0732	1	45	Low Pressure Seal	46-0727	3
12	O-ring	25-0370	1	29	Internal Snap Ring	46-0676	1	46	Low Pressure Retainer	46-0726	3
13	Oil Sight Glass	46-0670	1	30	Bearing Cap	46-0725	1	47	O-ring	25-0399	3
14	Oil Reflector	46-0824	1	31	Valve Cap	39-0087	6	48	Low Pressure Seal	N/A	3
15	Oil Sight Glass Spring Retainer	46-0671	1	32	O-ring	25-0160	6		High Pressure Seal Kit (Inc. 3 each 43, 45, 47)	70-0181	
16	O-ring	25-0398	1	33	Single Valve Assembly (See 70-0161)	N/A Sep.	6		Support Ring Kit (Inc. 3 each 42)	70-0182	
17	Connecting Rod	46-0720	3	34	O-ring	25-0386	6		Valve Kit (Inc. 6 each 33-34)	70-0161	


UNLOADER ASSEMBLY (8-0456)



8-0456-102405-JJF

UNLOADER ASSEMBLY (8-0456)								
REF. #	DESCRIPTION	PART #	QTY.		REF. #	DESCRIPTION	PART #	QTY.
1	Unloader Cap	7-0142	1		18	Piston	8-0442	1
2	Bolt	27-8433	1		19	O-ring	25-0389	1
3	Nut	30-3025	1		20	Nipple	8-0441	1
4	Unloader Knob	7-0141	1		21	O-ring	25-0388	1
5	Adjustment Barrel	8-0476	1		22	Inlet Bypass Adapter	8-0437	1
6	Pin	8-0477	1		23	Washer	8-0439	1
7	Spring Button	8-0475	1		24	Washer	8-0440	1
8	Spring	49-0132	1		25	Adapter	8-0438	1
9	Spring Guide	8-0474	1		26	Adapter	8-0448	1
10	Spring Button	8-0445	1		27	Washer	8-0449	1
11	Poppet	8-0443	1		28	Unloader Body	8-0451	1
12	Pin	8-0444	1		29	O-ring	25-0391	1
13	Back-up Ring	25-0396	1		30	Check Valve	8-0454	1
14	O-ring	25-0390	1		31	Check Valve Spring	49-0123	1
15	Washer	8-0450	1		32	O-ring	25-0372	1
16	Back-up Ring	25-0395	2		33	Adapter Nipple	24-0159	1
17	O-ring	25-0371	2			Unloader Repair Kit (Inc. 13, 14, 16, 17, 19, 21, 29)		70-0180

GUN ASSEMBLY (16-0001)



GUN ASSEMBLY (16-0001)			
REF. #	DESCRIPTION	PART #	QTY.
1	Plastic Housing	16-0008	1
2	Screw	27-3230	2
3	Brass Housing	16-0012	1
4	Gun Repair Kit	70-0055	1
5	Brass Plug	39-0024	1
6	Plastic Cover	16-0009	1
7	Pipe Assembly	16-0013	1
8	Trigger Pin	16-0063	1
9	Trigger/Safety Lock-off	16-0010	1
10	Pipe Assembly- Inlet	16-0016	1
	Complete Gun Assembly	16-0001	1

