

Mi-T-M[®] CORPORATION

8650 Enterprise Drive, Peosta IA 52068
319-556-7484 / Fax 319-556-1235

PARTS LIST FOR **HSE-2504-0M10/0M30** **HSE-3004-0M10/0M30** **HSE-3504-0M10/0M30** **(AFTER SERIAL #22664)**

PUMP OIL GRADE:
PUMP OIL CAPACITY:
FUEL NOZZLE:
BTU INPUT:
PRESSURE NOZZLE SIZE:
FOR HSE-2504/3004:
FOR HSE-3504:

Mi-T-M AW-4085-0016
40.6 oz. / 1.2 liters
1.75 60°B Delavan
294,000
4.0
3.5

This Parts Listing has been compiled for your benefit. You can be assured your Mi-T-M hot water pressure washer was constructed and designed with quality and performance in mind using over 25 years experience in the pressure washer business. Each component has been rigorously tested to insure the highest level of acceptance.

The contents of this Parts Listing are based on the latest product information available at the time of publication. The manufacturer reserves the right to make changes in price, color, materials, equipment, specifications or models at any time without notice.

WARNING

THIS IS A PROFESSIONAL HIGH PRESSURE, HOT WATER PRESSURE WASHER. CAUTION SHOULD BE OBSERVED WHEN USING OR REPAIRING THIS UNIT! READ AND FOLLOW THE SAFETY WARNINGS LISTED BELOW BEFORE ATTEMPTING ANY REPAIRS ON THIS PRESSURE WASHER!

SAFETY WARNINGS

1. NEVER alter or modify the equipment. Be sure any accessory items and system components being used will withstand the pressure developed. Use only genuine Mi-T-M parts for repair of your pressure washer. Failure to do so can cause hazardous operating conditions and will VOID warranty.
2. This unit has multiple safety devices which should never be altered, modified, removed or made inoperable. If a device fails, replace immediately with only genuine manufacturer replacement parts.
3. Electrical System: The unit must be connected to a properly grounded electrical source which provides the correct voltage and adequate fuse protection. Disconnect from power source when making repairs. Never assume the pressure washer is safe to work on just because it is not operating. It could restart at any time. Never operate the pressure washer with electrical enclosures open, removed or damaged. Do not allow metal components of the pressure washer to come in contact with live electrical components.
4. Do not operate the unit without all protective covers in place. Know how to stop and bleed pressures quickly. Be thoroughly familiar with controls.
5. Before servicing the unit, turn unit off, and trigger the gun to release trapped pressure. Do not make repairs while the unit is running. Service in a clean, dry, flat area.
6. After testing the machine, DO NOT leave the pressurized unit unattended. Shut off the unit and release trapped pressure before leaving.

Table of Contents


SPECIFICATIONS	3
FLOW CHART	4
GENERAL THEORY OF OPERATION	5
SAFETY DECAL PLACEMENT	6
FRAME ASSEMBLY	8
FLOAT TANK/PUMP/UNLOADER ASSEMBLY	10
HIGH PRESSURE PUMP (3-0079)	12
UNLOADER (850-0252)	14
PRESSURE SWITCH (22-0171)	16
BELTGUARD/SHEAVE ASSEMBLY	18
COIL DRAIN PLUG (850-0218)	19
HEAT EXCHANGER/BLOWER MOTOR	20
BOILER ASSEMBLY (850-0240)	22
GUN/WAND (850-0181) & ADJUSTABLE PRESSURE DUAL LANCE (850-0180 AND 850-0185)	24
FUEL TANK (850-0243)	26
FUEL PUMP (3-0020)	28
FUEL SOLENOID (44-0101)	29
CONTROL PANEL	30
ELECTRIC PANEL SINGLE PHASE	32
ELECTRIC PANEL THREE PHASE	34
WIRING DIAGRAM/SCHEMATIC FOR HSE-2504-0M10 (208-230 VOLT)	36
WIRING DIAGRAM/SCHEMATIC FOR HSE-3004-0M10 (208-230 VOLT)	37
WIRING DIAGRAM/SCHEMATIC FOR HSE-3504-0M10 (208-230 VOLT)	38
WIRING DIAGRAM/SCHEMATIC FOR HSE-2504/3004/3504-0M30 (208-230 VOLT)	39

SPECIFICATIONS

HSE-2504/3004/3504-0M10/0M30

MODEL NUMBER	HSE-2504-0M10	HSE-2504-0M30	HSE-3004-0M10	HSE-3004-0M30	HSE-3504-0M10	HSE-3504-0M30
Operating Pressure (PSI/Bar):	2500/ 172		3000/ 207		3500/ 241	
Water Volume (GPM/lpm):	3.2/ 12.1		3.5/ 13.3		3.3/ 12.5	
Outlet Water Temperature (F/C):		140°F/ 78°C (+/- 10°F) rise above inlet ambient (210°F/ 99°C maximum)				
Electrical System:						
Phase	Single	Three	Single	Three	Single	Three
Hz			60			
Voltage	208-230	208-230/460	208-230	208-230/460	208-230	208-230/460
Total System Amperage	25	16/8	36	24/12	39	28/14
On/Off Switch			Industrial Cam Switch			
Motor (Pump):		TEFC				
Horsepower	6		8		10	
RPM		1750				
Amperage	23.5	14.8/7.4	34.5	22/11	37.5	25/12.5
Service Factor	1.15		1.00	1.15	1.00	1.15
High Pressure Pump:		Belt Driven, Oil Bath, Triplex Piston				
Oil Type		SAE20-40W				
Oil Capacity (oz./liters)		16/.47				
Plungers		Ceramic				
Manifold		Forged Brass				
Valves		Stainless Steel				
Water System:						
Inlet Water Strainer		Removable Bowl for inspection and cleaning of Stainless Steel Screen				
Float Tank Capacity (Gal./ Liters)		1.2/ 4.5				
Unloader		Pressure Trapping, Preset				
Heat Dump Valve		Relieves heated water during unloader bypass stage				
Detergent System		Adjustable high pressure				
Burner Fuel System:						
Fuel Type		No.1 or No.2 Fuel Oil, Diesel or Kerosene				
Fuel Capacity (Gal./liters)		14/ 53				
Fuel Filter/ Water Separator		Spin on (10 micron) filter/ E-Z water drain				
Fuel Pump		Two Line, Single Stage				
Fuel Pressure (PSI/ BAR)		145/ 10				
Fuel Nozzle		1.75 60° B Delavan				
Fuel Consumption (GPH/ LPH)		2.1/ 7.9 Cont. Burning				
Burner Electrical System:						
Voltage		208/ 230				
Amps		1.5				
Heat Exchanger:		Vertical, Top Fired, Dual Spiral Coil				
BTU Input		294,000				
Efficiency		86% with #2 Fuel Oil/ Diesel				
Smoke Density		0-3 per ASTM D2156				
Safety Relief:						
Pressure Switch		Shuts off burner fuel supply upon trigger release				
High Limit Switch		Shuts off burner fuel supply when outlet water temperature exceeds 210°F/ 99°C				
Fuel Solenoid Valve		120 Volt, controls fuel supply to burner				
Safety Relief		Relieves excess system pressure				
High Pressure Nozzle:		4		3.5		
Unit Net Weight (Lbs/Kg)	564/256	558/253	607/276	595/270	631/286	612/278
Unit Shipping Weight (Lbs/Kg)	694/315	688/312	737/335	732/332	761/345	742/337
Unit Net Dimension (In/Cm)			49.5Lx28Wx40.5H/126Lx70Wx103H			
Unit Shipping Dimension (In/Cm)			57.5Lx35.5Wx59.5H/146Lx90Wx151H			

FLOW CHART



OMHSE064-120998-BAR

GENERAL THEORY OF OPERATION

WATER FLOW: Connect a pressurized water source to the INLET GARDEN HOSE CONNECTION (1) and turn on the water supply. The water will flow through a WATER STRAINER (2) which has a removable inspection bowl and then through a FLOAT VALVE (3) into a WATER FLOAT TANK (4).

The water is then drawn into the TRIPLEX HIGH PRESSURE PUMP (5) which has an UNLOADER (6) that bypasses the water when the trigger gun is closed. To protect the pump from heated water during this bypass stage, a HEAT DUMP VALVE (7) will open at 140°F/60°C allowing the heated water to escape. The Heat Dump Valve automatically resets when the water cools. Attached to the pump is a PRESSURE SWITCH (8) that controls the fuel supply to the burner.


When using detergents, the solution passes through the DETERGENT STRAINER (9) located on the DETERGENT HOSE (10). The detergent solution then travels through the DETERGENT METERING VALVE (11).

From there, the water may be allowed to flow out of the DRAIN PLUG (12) or through HEAT EXCHANGER INLET (13) where it is heated when the burner is on. As the water exits the HEAT EXCHANGER OUTLET (14), It enters a safety system which protects the operator from danger. The safety system contains a HIGH TEMPERATURE LIMIT SWITCH (15) which senses the water temperature and shuts off the fuel supply to the burner if it gets too hot. If the unloader fails to bypass water or the burner remains on when the trigger gun is closed, the SAFETY RELIEF (16) will relieve and allow water to exit safely.

The heated water then flows through the HIGH PRESSURE HOSE (17) and to the TRIGGER GUN ASSEMBLY (18) which allows the operator to control the water spray. When the trigger gun is open, the water flows through the ADJUSTABLE PRESSURE DUAL LANCE (19) and exits the NOZZLE (20).

FUEL FLOW: The Fuel Pump draws fuel from the FUEL TANK (21) through a replaceable FUEL FILTER/WATER SEPARATOR (22) and into the FUEL PUMP (23). Fuel exits the fuel pump, into a FUEL SOLENOID VALVE (24) which controls fuel flow to the FUEL NOZZLE (25) where it ignites and burns in the heat exchanger.

SAFETY DECAL PLACEMENT




OMHSE021-050798-BAR

OMHSE021-050798BAR

SAFETY DECAL PLACEMENT

REF. #	DESCRIPTION	PART #	QTY.	REF. #	DESCRIPTION	PART #	QTY.
1	Decal- Die Cut 2504	34-0512	2	13	Decal- Warning: Hang Tag (HSE-2504-0M10) (E/S)	34-0417	1
-	Decal- Die Cut 3004	34-0105	2	-	Decal- Warning: Hang Tag (HSE-2504-0M30,3504-0M10/0M30) (E/S)	34-0860	1
-	Decal- Die Cut 3504	34-0034	2	14	Decal- Stripe w/Logo	34-0725	1
2	Mi-T-M Small Logo	62-0087	1	15	Decal- Warning: Don't Modify Plumbing (E/S)	34-0807	1
3	Decal- Stripe	34-0501	1	16	Decal- Clear Laminate	N/A	1
4	Decal- Pump Oil Drain (E/S)	34-0853	1	17	Decal- Data Plate	N/A	1
5	Decal- Warning: Guard in Place (E/S)	34-0826	1	18	Decal- Serial Number	N/A	1
6	Decal- Warning: Do Not Use Gasoline (E/S)	34-0806	1	19	Decal- Stripe	34-0560	1
7	Decal- American Flag	34-0521	1	20	Mi-T-M Large Logo	62-0093	1
8	Decal- Caution: Auto Start/Stop Option (E/S)	34-0864	1	21	Decal- Warning: Hot Coil Exhaust (E/S)	34-0808	1
9	Decal- Steam Instructions Option (E/S)	34-0863	1	22	Decal- Terminal Stripe	34-0867	1
10	Decal- Pump I.D.	34-0396	1	23	Decal- Warning/Cauiton/Operation (HSE-2504-0M10) (E/S)	34-0859	1
11	Decal- Detergent Adjustment (E/S)	34-0809	1	-	Decal- Warning/Cauiton/Operation (HSE-2504-0M30/3004,3504-0M10/0M30) (E/S)	34-0861	1
12	Cable Tie	33-0022	1	24	Decal- Off/Pump/Burner/Steam (Spanish Only)	34-0862	1

FRAME ASSEMBLY




OMHSE016-102798-BAR

FRAME ASSEMBLY

REF #	DESCRIPTION	PART #	QTY.	REF #	DESCRIPTION	PART #	QTY	REF #	DESCRIPTION	PART #	QTY
1	Float Tank/Pump/Unloader Assy. (See Exploded Drawing)	N/A Sep.	1	23	Control Panel Assembly (See Page 24)	N/A Sep.	1	40	Beltguard/Sheave Assembly (See Exploded Drawing)	N/A Sep.	1
2	Hose Barb	23-0005	1	24	Bolt	27-0118	2	41	Hex Nut	30-3023	4
3	Flatwasher	28-0022	12	25	Bolt	27-0576	1	42	Conduit: HSE-2504/3004-3M10/0M30 HSE-3504-0M30 *(One Foot Required)	32-0486	1
4	Bolt	27-9524	18	26	Flatwasher	28-0023	3	-	Conduit: HSE-3504-0M10 *(One Foot Required)	32-0510	1
5	Elbow	23-0344	1	27	Bracket-Tightener Angle	13-0003A01	1	43	Conduit	32-0488	1
6	Gasket	26-0001	1	28	Locknut	30-0159	2	44	Hex Nut	30-3030	4
7	Garden Hose Swivel	23-0095	1	29	Plug	24-0034	1	45	Heat Exchanger Assembly (See Exploded Drawing)	N/A Sep.	1
8	Water Filter Assembly (Includes 9-12)	19-0003	1	30	Bushing/Electrical	32-0465	1	46	Knob	62-0057	2
9	Strainer Body	19-0021	1	31	Trim Lock	33-0020	1	47	Flatwasher	28-0001	2
10	Gasket w/Strainer Bowl (See 19-0003)	N/A Sep.	1	32	Hose Barb	23-0073	1	48	Hood Assembly- Blue	850-0244	1
11	Stainless Steel Screen	19-0023	1	33	Hose Clamp	42-0004	1	49	GunLance Assembly	850-0181	1
12	Strainer Bowl	19-0022	1	34	Hose	15-0020	2	50	High Pressure Hose Assembly HSE-2504-3M10	15-0146	1
13	Frame Assembly	5-0138A01	1	35	Hex Nut	30-0161	4	-	High Pressure Hose Assembly HSE-3004/3504-3M10	15-0166	1
14	Pneumatic Tire	14-0072	4	36	Flatwasher	28-0030	8	51	Screw Connect	17-0035	1
15	Nut	30-0117	4	37	Bolt	27-0166	4	52	Adjustable Pressure/Dual Lance: HSE-2504/3004-3M10	850-0185	1
16	Bolt	27-8040	2	38	Motor: HSE-2504-3M10	2-0090	1	-	Adjustable Pressure/Dual Lance: HSE-3504-3M10	850-0180	1
17	Fuel Hose-Return Line	15-0190	1	-	Motor: HSE-2504-3M30	2-0091	1	53	High Pressure Nozzle: 1504 HSE-2504/3004-3M10/0M30	18-0054	1
18	Fuel Hose-Inlet Line	15-0147	1	-	Motor: HSE-3004-3M10	2-0092	1	-	High Pressure Nozzle: 1503.5 HSE-3504-3M10/0M30	18-0254	1
19	Fuel Tank Assembly	850-0243	1	-	Motor: HSE-3004-3M30	2-0093	1		*Must Order In One Foot Lengths		
20	Electric Panel Assembly (See Exploded Drawing)	N/A Sep.	1	-	Motor: HSE-3504-3M10	2-0094	1				
21	Screw	27-8922	4	-	Motor: HSE-3504-3M30	2-0095	1				
22	Bolt	27-9527	4	39	Bolt	27-8923	4				


FLOAT TANK/PUMP/UNLOADER ASSEMBLY



OMHSE017-101398-BAR

FLOAT TANK/PUMP/UNLOADER ASSEMBLY								
REF. #	DESCRIPTION	PART #	QTY.	REF. #	DESCRIPTION	PART #	QTY.	
1	Hose *(Four Feet Required)	15-0007	1	21	Bolt w/ Pump	27-8471	1	
2	Hose Clamp	42-0011	3	22	Hose Barb	23-0045	1	
3	Hose Barb	23-0105	1	23	Cross	22-0171	1	
4	Elbow	23-0307	1	24	Heat Dump Valve	22-0208	1	
5	Locknut	23-0138	2	25	Branch Tee	23-0127	1	
6	Float Tank	12-0066	1	26	Elbow	23-0119	1	
7	O-ring	25-0427	1	27	Detergent Strainer w/ Check Valve	19-0056	1	
8	Restrictor	23-0351	1	28	Detergent Hose	15-0021	6	
9	Float Valve Assembly	850-0238	1	29	Detergent Valve	22-0226	1	
10	Float Tank Cap	39-0100	1	30	Reducer	23-0056	1	
11	High Pressure Hose Assembly	15-0192	1	31	Hex Nut	23-0012	1	
12	Manifold Block	51-0022	1	32	Street Tee	23-0058	1	
13	Plug	24-0034	2	33	High Pressure Pump Assembly	3-0079	1	
14	Hex Nipple	24-0024	1	34	Decal-Pump I.D.	34-0396	1	
15	Unloader Assembly	850-0252	1	35	Pump Key	43-0048	1	
16	Pressure Switch	22-0171	1	36	Elbow	23-0123	1	
17	Elbow	23-0306	1	37	Hose Clamp	42-0004	1	
18	High Pressure Hose Assembly	15-0194	1	38	Hose	15-0020	2	
19	Lockwasher- Black	5-0101A01	1	*Must Order in One Foot Lengths				
20	Bolt	29-0055	4					

HIGH PRESSURE PUMP (3-0079)




TORQUE SPECS.	
POSITION	FT-LBS
1	29.4
3	29.4
7	73.7
8	22.1
25	14.7
31	14.7
40	14.7
43	7.3
44	14.7
45	14.7
54	29.4

HIGH PRESSURE PUMP (3-0079)


REF. #	DESCRIPTION	PART #	QTY.	REF. #	DESCRIPTION	PART #	QTY.	REF. #	DESCRIPTION	PART #	QTY.
1	Hex Plug	39-0018	1	21	Seal Retainer	46-0057	3	41	O-ring Cover	25-0339	1
2	Washer	28-1002	1	22	O-ring	25-0015	3	42	Crankcase Cover	46-0295	1
3	Hex Plug	39-0019	1	23	Oil Seal	26-0047	3	43	Bolt	27-8404	5
4	Washer	28-1038	1	24	Bushing	9-0029	3	44	Hex Plug	39-0017	1
5	Valve Assy. (Includes 11-15) (See 70-0009)	N/A Sep.	6	25	Bolt	27-8431	8	45	Oil Level Indicator	46-0114	1
6	O-ring	25-0012	6	26	Crankcase Cover-Closed	46-0336	1	46	Connecting Rod Pin	43-0032	3
7	Valve Plug	39-0020	6	27	O-ring	25-0013	2	47	Retaining Ring	46-0103	6
8	Bolt	27-8185	8	28	Roller Bearing	48-0012	2	48	Crankshaft	46-0050	1
9	Flatwasher	28-1039	8	29	Crankcase	46-0047	1	49	Key	43-0048	1
10	Pump Manifold - Brass 20mm	46-0060	1	30	Oil Dipstick	46-0144	1	50	Oil Seal	26-0049	1
11	O-ring (See 70-0009)	N/A Sep.	6	31	Piston Bolt	46-0069	3	51	Shim	46-0113	1
12	Valve Seat (See 70-0009)	N/A Sep.	6	32	Washer	28-0400	3	52	Crankcase Cover-Open	46-0296	1
13	Valve Plate (See 70-0009)	N/A Sep.	6	33	O-ring	25-0014	4	53	Lockwasher	29-0055	4
14	Valve Spring (See 70-0009)	N/A Sep.	6	34	Back-up Ring	46-0109	3	54	Bolt	27-8471	4
15	Valve Cage (See 70-0009)	N/A Sep.	6	35	Plunger	46-0052	3		Valve Kit (6 each of 11-15)	70-0009	
16	High Pressure Head Ring (See 852-0122)	N/A Sep.	3	36	Slinger Washer	46-0146	3		Head Ring Kit (3 each of 16)	70-0030	
17	High Pressure V-Packing (See 852-0122)	N/A Sep.	3	37	Piston Rod	46-0056	3		Packing Kit (3 each of 17, 18, 20)	70-0147	
18	Stop Ring Packing (See 852-0122)	N/A Sep.	3	38	Connecting Rod	46-0051	3		Packing Assy. (3 each of 16, 17, 18, 20, 22)	852-0122	
19	Intermediate Ring	46-0659	3	39	Lockwasher	29-0154	6		Intermediate Retainer Kit (3 each 18, 19)	70-0148	
20	Low Pressure Seal (See 852-0122)	N/A Sep.	3	40	Bolt	27-8435	6				

UNLOADER (850-0252)



UNLOADER (850-0252)			
REF. #	DESCRIPTION	PART #	QTY.
1	Hex Nut	8-0362	2
2	Cover	7-0098	1
3	Set Screw	27-4280	1
4	Adjusting Insert- Brass	8-0363	1
5	Adjustment Nut	8-0364	1
6	Set Screw	8-0365	1
7	Glide Ring	8-0366	1
8	Spring	49-0104	1
9	Hex Nut	8-0367	1
10	Bushing	8-0368	1
11	Unloader Body	8-0369	1
12	Retainer	8-0269	1
13	Valve Housing	8-0104	1
14	Spring	49-0023	1
15	Valve	8-0105	1
16	O-ring	25-0036	1
17	Cylinder Pin	8-0372	1
18	Piston Repair Kit	70-0243	1
19	Spacer	8-0371	1
20	Stop Nut	8-0157	1
21	Washer	29-0154	2
	Check Valve Repair Kit (Includes 13-16)	70-0244	
	Unloader Complete	850-0252	

PRESSURE SWITCH (22-0171)




22-0171&22-0243-120799-BAR

PRESSURE SWITCH (22-0171)			
REF. #	DESCRIPTION	PART #	QTY.
1	Pressure Switch	22-0171	1
2	Screw	N/A	4
3	Cover	N/A	1
4	O-ring (See 70-0306)	N/A Sep.	1
5	Micro Switch	N/A	1
6	Retainer Clip	N/A	1
7	Body	N/A	1
8	O-ring (See 70-0306)	N/A Sep.	2
9	Back-up Ring (See 70-0306)	N/A Sep.	1
10	Piston	N/A	1
11	Washer	N/A	1
12	Spring	49-0144	1
13	Washer	N/A	1
14	Plastic Housing	N/A	1
15	O-ring (See 70-0306)	N/A Sep.	1
16	Nut	N/A	1
17	Wire Assembly	N/A	1
	O-ring Repair Kit (Inc. 4, 8-9, 15)	70-0306	

BELTGUARD/SHEAVE ASSEMBLY

OMHSE019-050598-BAR




BELTGUARD/SHEAVE ASSEMBLY			
REF. #	DESCRIPTION	PART #	QTY.
1	Decal-2504	34-0512	1
-	Decal-3004	34-0105	1
-	Decal-3504	34-0034	1
2	Beltguard Cover Assembly (Includes 3-8)	850-0242	1
3	Mi-T-M Logo	62-0086	1
4	Decal- Stripe	34-0501	1
5	Fastener	33-0197	1
6	Rubber Grommet	33-0001	5
7	Beltguard Cover- Black	6-0064A01	1
8	Trimlock *(Five Feet Required)	33-0020	1
9	Decal-American Flag	34-0521	1
10	Bolt	27-0015	4
11	Motor Bushing (HSE-2504)	9-0010	1
-	Motor Bushing (HSE-3004/3504)	9-0008	1
12	Pump Bushing	9-0017	1
13	Belt (HSE-2504/3504)	11-0001	2
-	Belt (HSE-3004)	11-0017	2
14	Motor Sheave (HSE-2504)	10-0065	1
-	Motor Sheave (HSE-3004)	10-0036	1
-	Motor Sheave (HSE-3504)	10-0041	1
15	Pump Sheave	10-0038	1
16	Backplate Assembly (Includes 8, 17, 18)	850-0241	1
17	Decal-Warning: Beltguard in Place	34-0826	1
18	Backplate (See 850-0241)	N/A Sep.	1
19	Pump Key	43-0048	1
20	Motor Key	N/A	1

*Must Order in One Foot Lengths

OMHSE019-050598-BAR

COIL DRAIN PLUG (850-0218)




850-0218-041597-BAR

COIL DRAIN PLUG (850-0218)			
REF. #	DESCRIPTION	PART #	QTY.
1	Bolt	27-9526	1
2	Retaining Cable	33-0260	1
3	Snap Ring	33-0261	1
4	Hand Wheel	16-0239	1
5	Plug	24-0147	1
6	Back-up Ring	25-0424	1
7	O-ring	25-0423	1

8500218-041597-BAR


HEAT EXCHANGER/BLOWER MOTOR



OMHSE018-101298-BAR

HEAT EXCHANGER/BLOWER MOTOR							
REF. #	DESCRIPTION	PART #	QTY.	REF. #	DESCRIPTION	PART #	QTY.
1	Heat Exchanger Assembly	850-0240	1	21	Blower Motor-240 Volt	2-0086	1
2	Nut	30-3022	1	22	Screw w/Blower Fan	30-3031	1
3	Bolt	27-8898	3	23	Insulator	32-0375	2
4	Clamp	33-0291	1	24	Electrode Connector Cap	44-0083	2
5	Blower Fan	44-0103	1	25	Electrode Boot	32-0418	2
6	Shim- Black	20-0460A01	1	26	Elbow	23-0287	1
7	Bolt	27-9524	2	27	Fuel Solenoid-120 Volt	44-0101	1
8	High Pressure Fuel Hose Assembly	15-0165	1	28	Elbow	23-0249	1
9	Elbow	23-0288	1	29	High Limit Temperature Switch	32-0423	1
10	Elbow	23-0237	1	30	Coil Outlet Block	24-0138	1
11	Fuel Water Separator	19-0070	1	31	Adapter	23-0369	1
12	Fuel Water Separator Bowl	19-0071	1	32	Pressure Relief Valve	22-0273	1
13	Fuel Water Separator Strainer	19-0053	1	33	Pipe Nipple	24-0141	2
14	Elbow	23-0014	1	34	Adapter	23-0197	1
15	Valve	22-0265	1	35	High Pressure Hose Assembly	15-0192	1
16	Inlet Fuel Hose	15-0147	1	36	Street Tee	23-0058	1
17	Return Fuel Hose	15-0190	1	37	Elbow	23-0306	1
18	Elbow	23-0130	1	38	Adapter	23-0279	1
19	Fuel Pump	3-0020	1	39	Coil Drain Plug Assembly	850-0218	1
20	Coupler w/ Blower Motor	33-0265	1				


BOILER ASSEMBLY (850-0240)



BOILER ASSEMBLY (850-0240)


REF. #	DESCRIPTION	PART #	QTY.	REF. #	DESCRIPTION	PART #	QTY.
1	Nut	30-0121	2	15	Nut	30-6002	4
2	Plug	24-0034	1	16	Cone	20-0373	1
3	Heat Exchanger Outer Wrap Assembly-Black	20-0431A01	1	17	Electrode Plate	38-0046	1
4	Bolt	27-8879	2	18	Washer	28-0523	4
5	Air Diverter Plate-Black	20-0378A01	1	19	Electrode	32-0420	2
6	Air Diverter Stem Assembly-Black	20-0377A01	1	20	Bolt	27-9526	5
7	Lockwasher	28-1009	4	21	Electrode Mounting Clip	20-0446A01	2
8	Hex Nut	30-6001	4	22	Bolt	27-8878	4
9	Insulation Bottom	33-0250	1	23	Nozzle Holder	23-0292	1
10	Washer	28-0521	2	24	Snap Ring	33-0254	1
11	Heat Exchanger Coil	66-0011	1	25	Sight Glass	33-0252	1
12	Inner Pan Assembly	20-0372	1	26	Fuel Oil Nozzle	18-0308	1
13	Top Pan Assembly-Black	20-0371A01	1	27	Decal-Warning: Do Not Modify Plumbing (E/S)	34-0807	1
14	Lockwasher	28-1028	4				

GUN/WAND (850-0181) & ADJUSTABLE PRESSURE DUAL LANCE (850-0180 AND 850-0185)



GUN (850-0181) & ADJUSTABLE PRESSURE DUAL LANCE (850-0180 AND 850-0185)				
REF. #	DESCRIPTION	PART #	QTY.	
1	Gun/Lance Assembly (Includes 2-20)	850-0181	1	
2	Pipe Assembly	16-0016	1	
3	Plastic Housing	16-0008	1	
4	Screw	27-3230	2	
5	Housing	16-0012	1	
6	Gun Repair Kit	70-0055	1	
7	Plug	39-0024	1	
8	Cover	16-0009	1	
9	Trigger Safety Lock-off	16-0010	1	
10	Trigger Pin	16-0063	1	
11	Pipe Assembly	16-0013	1	
12	Adaptor	16-0283	1	
13	Pipe	16-0277	1	
14	Guard Lance (Right Side)	16-0320	1	
15	Screw	27-8382	6	
16	Guard Lance (Left Side)	16-0321	1	
17	Plug	39-0076	1	
18	Screw	49-0103	1	
19	Spacer	16-0282	1	
20	Lance Holder (See 16-0306)	N/A Sep.	1	
21	Dual Lance Assembly (Includes 22-42) 36"	850-0185	1	
-	Dual Lance Assembly (Includes 22-42) 48"	850-0180	1	
22	Handle Plug	16-0312	1	
23	Nut	30-3002	1	
REF. #				
24	Handle	16-0313	1	
25	Washer	28-1021	1	
26	Nut	30-3010	1	
27	Adaptor	23-0271	1	
28	O-ring	25-0351	1	
29	Piston	16-0314	1	
30	Back-up Ring	25-0352	1	
31	O-ring	25-0353	1	
32	Upper Protector	16-0315	1	
33	Screw	27-8862	1	
34	Lower Protector	16-0316	1	
35	Body	23-0272	1	
36	Lance w/Protective Cover 36"	16-0328	2	
-	Lance w/Protective Cover 48"	16-0317	2	
37	Nut	30-3060	2	
38	Pipe Clamp	16-0318	2	
39	Screw	27-8861	2	
40	Nipple	24-0127	2	
41	Nozzle Protector	16-0319	1	
42	Nozzle-6540	18-0110	1	
	Gun Assembly (Includes 12-20)	16-0001		
	Lance Assembly (Includes 13-21)	16-0306		
	O-ring Kit (Includes 28, 30, 31)	70-0143		

FUEL TANK (850-0243)




850-0243/041798/BAR

850-0243-041798-BAR

FUEL TANK (850-0243)			
REF #	DESCRIPTION	PART #	QTY
1	Plug	23-0296	1
2	Fuel Tank (See 850-0243)	N/A Sep.	1
3	Fuel Cap-Vented	12-0033	1
4	Decal-Warning: Risk of Fire E/S	34-0806	1
5	Fuel Pick-up Line	33-0296	1
6	Flare	23-0247	1
7	Elbow	23-0237	1
	Fuel Tank Assembly (Includes 1-7)	850-0243	


FUEL PUMP (3-0020)



0MHSP018A-041597-BAR

FUEL PUMP (3-0020)			
REF. #	DESCRIPTION	PART #	QTY.
1	Fuel Pump Complete - Right Hand	3-0020	1
2	Cover Screw	46-1006	4
3	Cover-Right Hand	46-1005	1
4	Strainer	19-0034	1
5	Cover Gasket	26-0109	1
6	Plug	24-0044	3
7	Body	N/A	1
8	Plug	24-0082	1


FUEL SOLENOID (44-0101)



0MHSP013-44-0101-121698-BAR

FUEL SOLENOID (44-0101)			
REF. #	DESCRIPTION	PART #	QTY.
1	Solenoid Complete-120V	44-0101	1
2	Solenoid Body	46-1013	1
3	Solenoid Piston	46-1012	1
4	Solenoid Base	46-1014	1
5	Screw (See 44-0101)	N/A Sep.	2
6	Solenoid Coil-120V	46-1020	1
7	Spring (See 44-0101)	N/A Sep.	1
8	Piston Nut	46-1016	1
9	Din Connector Cord	32-0443	1


CONTROL PANEL



OMHSE020-050200-BAR


CONTROL PANEL			
REF. #	DESCRIPTION	PART #	QTY.
1	Control Panel	20-0432A01	1
2	Bolt	27-9526	2
3	Bolt	27-8899	4
4	Ignitor Bracket	20-0418A01	1
5	Ignitor- 240 Volts	850-0223	1
6	Hex Nut	30-0137	4
7	Bolt	27-8898	4
8	Hex Nut	30-3022	4
9	Cam Switch	32-0464	1
10	Envelope	41-0184	1
11	Locknut (HSE-2504/3004)	32-0292	2
-	Locknut (HSE-3504)	32-0515	1
12	Locknut	32-0108	7
13	Electric Box	32-0462	1
14	Strain Relief	32-0437	7
15	Plug	32-0514	2
16	Bushing	32-0488	1
17	Conduit (HSE-2504-0M10/30, HSE-3004-0M10/30, HSE-3504-0M30) *(One Foot Required)	32-0486	1
-	Conduit (HSE-3504-0M10) *(One Foot Required)	32-0510	1
18	Strain Relief	9-0046	1
-	Strain Relief (HSE-3504-0M10)	9-0048	1
19	Power Cord w/GFCI Plug (HSE-2504-0M10)	32-0334	1
-	Power Cord (HSE-2504-0M30) *(Fourty Feet Required)	32-0025	1
-	Power Cord (HSE-3004-0M10) *(Fourty Feet Required)	32-0021	1
-	Power Cord (HSE-3004/3504-0M10) *(Fourty Feet Required)	32-0023	1
-	Power Cord (HSE-3504-0M10) *(Fourty Feet Required)	32-0504	1
20	Plug (HSE-2504-0M30)	32-0118	1
-	Plug (HSE-3004/3504-0M10)	32-0012	1
-	Plug (HSE-3004/3504-0M30)	32-0037	1
*Must Order in One Foot Lengths.			

ELECTRIC PANEL SINGLE PHASE



ELECTRIC PANEL SINGLE PHASE								
REF. #	DESCRIPTION	PART #	QTY.	REF. #	DESCRIPTION	PART #	QTY.	
1	Electric Panel- Gray	20-0434A14	1	13	Capacitor Bracket- Black	20-0437A01	1	
2	Transformer	32-0313	1	14	Run Capacitor (HSE-2504)	32-0518	2	
3	Starwasher	28-1009	6	-	Run Capacitor (HSE-3004)	32-0520	2	
4	Bolt	27-8835	8	-	Run Capacitor (HSE-3504)	32-0519	2	
5	Overload Relay (HSE-2504)	32-0484	1	15	Washer (HSE-2504/3504)	28-0001	1	
-	Overload Relay (HSE-3004)	32-0485	1	-	Washer (HSE-3004)	28-0002	1	
-	Overload Relay (HSE-3504)	32-0490	1	16	Bolt (HSE-2504/3504)	27-0759	1	
6	Din Rail (One Foot Required)	32-0316	1	-	Bolt (HSE-3004)	27-0038	1	
7	Contactor (HSE-2504)	32-0478	1	17	Foam Pad	N/A	1	
-	Contactor (HSE-3004)	32-0479	1	18	Safe Touch Cover	32-0508	1	
-	Contactor (HSE-3504)	32-0480	1	19	Safe Touch Cover	32-0507	1	
8	Fuse Holder (HSE-3004/3504)	32-0473	2	20	Fuse	32-0467	2	
9	Fuse (HSE-3004/3504)	32-0470	2	21	Fuse	32-0471	1	
10	Hex Nut (HSE-2504/3504)	30-0154	1	22	Hex Nut	30-3022	2	
-	Hex Nut (HSE-3004)	30-0155	1	23	Bolt	27-8898	1	
11	Capacitor Clamp (HSE-2504/3504)	20-0467	2	24	Terminal Strip	32-0463	1	
-	Capacitor Clamp (HSE-3004)	20-0467	4	25	Decal-Number Strip	34-0867	1	
12	Start Capacitor (HSE-2504/3504)	32-0516	2	*Must Order in One Foot Lengths				
-	Start Capacitor (HSE-3004)	32-0517	4					


ELECTRIC PANEL THREE PHASE




OMHSE022-012900-BAR

ELECTRIC PANEL THREE PHASE			
REF. #	DESCRIPTION	PART #	QTY.
1	Electric Panel	20-0434A14	1
2	Transformer	32-0313	1
3	Starwasher	28-1009	4
4	Bolt	27-8835	6
5	Overload Relay (HSE-2504-0M30)	32-0483	1
-	Overload Relay (HSE-3004/3504-0M30)	32-0484	1
6	Din Rail (One Foot Required)	32-0316	1
7	Contactor (HSE-2504-0M30)	32-0477	1
-	Contactor (HSE-3004/3504-0M30)	32-0478	1
8	Safe Touch Cover	32-0508	1
9	Safe Touch Cover	32-0507	1
10	Fuse	32-0467	2
11	Fuse	32-0471	1
12	Hex Nut	30-3022	2
13	Bolt	27-8898	1
14	Terminal Strip	32-0463	1
15	Decal- Number Strip	34-0867	1
*Must Order in One Foot Lengths			


WIRING DIAGRAM/SCHEMATIC FOR HSE-2504-0M10 (208-230 VOLT)



WIRING DIAGRAM/SCHEMATIC FOR HSE-3004-0M10 (208-230 VOLT)



WIRING DIAGRAM/SCHEMATIC FOR HSE-3504-0M10 (208-230 VOLT)



WIRING DIAGRAM/SCHEMATIC FOR HSE-2504/3004/3504-0M30 (208-230 VOLT)

